







## How to Connect to a Wireless Projector

1. Turn on your Projector as normal
2. Make sure the Input Setting is set to **HDMI** by pressing **Input** on the remote and selecting **HDMI** from the menu
3. Your projector screen (Smartboard) should look like the following with your school and Room number displayed. You are now ready to connect your laptop to the projector wirelessly.




4. On your laptop keyboard Press Windows Key + P  +  at the same time.
5. This menu will display on the side of you screen



Select  
"Connect to a Wireless Display"


Then Select **your Room** out of the list

(Flip Page for more)





6. The 1<sup>st</sup> time you connect to a projector from your laptop it will prompt for a PIN Code





- The code you need to enter will be displayed on the projector screen.





- . Enter the code in the box on the laptop

\*\*\* The next time you connect to the same projector you will not have to enter the code

7. To change the projection between duplicate screens or extended desktop

- Click “Change Projection Mode” or you can Press Windows Key + P  +  again at any time.



8. When connected you will get the following bar at the top of your screen. You can minimize it by clicking the push pin icon. To get it back just move your mouse to the top of the screen.

